

2013-2014 HD APPLICATION GUIDE - SCHOOL BUSES

| <i>Year</i> | <i>Model</i> | <i>Size</i> | <i>HD Part #</i> | <i>CFB Part #</i> | <i>Winter Blade Part #</i> | <i>Arm Type</i> |
|--------------------------------|-------------------------------|-------------|------------------|-------------------|----------------------------|-----------------|
| American Transportation | | | | | | |
| 2001-1998 | AmTran RE | 24 | | 11241 | 80241 | 1/4 Pin |
| 1997-1995 | AmTran RE | 28 | 77281 | | | Wide Saddle |
| 2001-1998 | Conventional Chassis | 22 | | 11221 | 80221 | 9x4 Hook |
| 1997-1992 | Conventional Chassis | 16 | | 11161 | 80161 | 9x4 Hook |
| 2001-1996 | Genesis | 24 | 77241 | | 76241 | Wide Saddle |
| Blue Bird | | | | | | |
| 2010-2006 | All American | 22 | 77221 | | | Wide Saddle |
| 2003-1990 | All American (curved) | 20 | 73201 | | 76201 | Saddle |
| 2003-1990 | All American (flat) | 18 | 73181 | | 76181 | Saddle |
| 1989-1970 | All American (curved) | 20 | 73201 | | 76201 | Saddle |
| 1989-1970 | All American (flat) | 18 | 73181 | | 76181 | Saddle |
| 2003-1975 | Conventional Chassis (curved) | 18 | 73181 | | 76181 | Saddle |
| 2003-1975 | Conventional Chassis (flat) | 18 | 71181 | | 76181 | Saddle |
| 1998-1997 | TC 1000 (curved) | 24 | 77241 | | | Wide Saddle |
| 1998-1997 | TC 1000 (flat) | 22 | 77221 | | | Wide Saddle |
| 2002-1993 | TC 2000 (curved) | 24 | 77241 | | | Wide Saddle |
| 2002-1993 | TC 2000 (flat) | 22 | 77221 | | | Wide Saddle |
| 1992-1991 | TC 2000 | 20 | 73201 | | 76201 | Saddle |
| 1990-1987 | TC 2000 | 18 | 73181 | | 76181 | Saddle |
| 2010-2008 | Vision | 18 | | 11181 | 80181 | 9x4 Hook |
| 2007-2004 | Vision (curved) | 18 | 73181 | | 76181 | Saddle |
| 2007-2004 | Vision (flat) | 18 | 71181 | | 76181 | Saddle |
| Carpenter | | | | | | |
| 2003-1996 | Crown FE | 24 | 77241 | | | Wide Saddle |
| 2003-1996 | Crown Conventional Chassis | 18 | | 11181 | 80181 | 9x4 Hook |
| 1992-1987 | Conventional Chassis | 16 | 73161 | | 76181 | Saddle |
| Corbeil | | | | | | |
| 1992-1987 | Conventional Chassis | 18 | 73181 | | 76181 | Saddle |
| IC Bus | | | | | | |
| 2012 | AC | 22 | | 11221 | 80221 | 9x4 Hook |
| 2012 | AE | 22 | | 11221 | 80221 | 9x4 Hook |
| 2012-2006 | BE200 | 24 | | 11241 | 80241 | 9x4 Hook |
| 2006-2002 | CE200 | 22 | | 11221 | 80221 | 9x4 Hook |

| | | | | | | |
|---------------------------|----------------------|----|-------|-------|-------|-------------|
| 2011-2005 | CE300 | 24 | | 11241 | 80241 | 9x4 Hook |
| 2004-2002 | CE300 | 22 | | 11221 | 80221 | 9x4 Hook |
| 2007-2002 | FE | 24 | | 11241 | 80241 | ¼ Pin |
| 2008-2007 | RE300 | 24 | | 11241 | 80241 | ¼ Pin |
| 2006-2002 | RE | 24 | | 11241 | 80241 | ¼ Pin |
| Thomas Built Buses | | | | | | |
| 2007 | Conventional Chassis | 20 | 73201 | | 76201 | Saddle |
| 2004-1972 | Conventional Chassis | 18 | 73181 | | 76181 | Saddle |
| 2007-1992 | Saf-T-Liner | 28 | 77281 | | | Wide Saddle |
| 2012-2005 | Saf-T-Liner C2 D.S. | 28 | | 11281 | 80261 | 9x4 Hook |
| 2012-2005 | Saf-T-Liner C2 P.S. | 24 | | 11241 | 80241 | 9x4 Hook |
| Ward Body Works | | | | | | |
| 1991-1982 | Conventional Chassis | 16 | | 11161 | 80161 | 9x4 Hook |
| Wayne Works | | | | | | |
| 1990-1981 | Conventional Chassis | 18 | 73181 | | 76181 | Saddle |